








岡山シンフォニーホール
大ホール照明回路表








単相三線式300A
《カムロック》

天反 No.3	No.3 - 1	No.3 - 2	No.3 - 3	No.3 - 4	No.3 - 5	No.3 - 6		
天反 No.2	No.2 - 1	No.2 - 2	No.2 - 3	No.2 - 4	No.2 - 5	No.2 - 6		
天反 No.1	No.1 - 1	No.1 - 2	No.1 - 3	P1	P2	No.1 - 4	No.1 - 5	No.1 - 6

PTF
直調切換
60 直60A C型



CON



☆ FrはPar64 1N かCI-8H

☆ 2CLの1番10番の両端は凸レンズ
他はカッターライト

60

60 DMX (Ether) 客席最後部

60